

# PULLMAN-HOLT

## Rug Boss Renovation System For Carpets & Area Rugs

Introducing the Rug Boss Renovation System for Carpets and Area Rugs. It's Pullman-Holt's answer to removing stubborn stains and embedded dirt from carpet without bending down to hand scrub or flooding your carpet using bulky, power equipment. This low-moisture system uses encapsulation technology which is preferred by professional contractors and by the carpet manufacturers to clean, maintain and revitalize carpet without over-wetting (via extraction) and risking damage. First, spray dry foam formula on the area to be cleaned, then roll the patented brush back-and-forth to distribute the cleaning formula and agitate the carpet. Stains will be removed right away. The dirt and other materials will be encapsulated in crystal form during the brief drying period. The crystal is then removed with routing vacuuming. It's that easy to keep your carpets and area rugs looking like new again!



Rug boss Rug Renovator brush system includes a Patented dual bristle brush with wheels, telescoping handle and one can of our advanced encapsulation cleaning formula.

### Easy Four Step Process:



Step One: Apply foaming shampoo over desired area (not to exceed 4 square feet).



Step Two: Using back and forth movement, work foam into carpeted area. Use White bristles on carpet for light to medium cleaning and for sensitive fabrics.



Step Three: Use Black bristles on carpet for more aggressive cleaning and stain removal.



Step Four: Allow to dry and vacuum thoroughly.

**PULLMAN-HOLT**

10702 N. 46th St. • Tampa, FL 33617

800-237-7582 • Fax 800-833-8875

[www.Pullman-Holt.com](http://www.Pullman-Holt.com)

# PULLMAN-HOLT

## Rug Boss Renovation System For Carpets & Area Rugs

### Features:

- Brush roll radius automatically sets the bristles at proper angle to evenly distribute cleaner and provide deep down agitation of carpet fibers.
- Black bristles - aggressive agitation to remove stubborn, embedded dirt and stains. Excellent grooming tool for all types of carpet and for lifting and removing of pet hair.
- Helps propel brush roll easily over all types of carpet. Provides consistent angle and depth of bristles to maximize cleaning results.
- White bristles - light to medium aggressiveness for sensitive carpets
- Heavy duty steel handle adjust up to any comfortable operating height. Just twist and slide the retractable telescopic handle to the desired height then just tighten it securely.



Advanced encapsulation (crystallizing) formula is excellent for general cleaning and spot removal. Dirt particles are trapped inside of a polymer crystal and removed with routine vacuuming. Until removed, crystals double as a soil retardant to keep carpets cleaner longer. Safe to use on all types of carpeting, plus area, throw, oriental and sectional rugs. Dries quickly and leaves no sticky residue.

**PULLMAN-HOLT**

10702 N. 46th Street • Tampa, FL 33617  
800-237-7582 • Fax 800-833-8875  
[www.Pullman-Holt.com](http://www.Pullman-Holt.com)