

HOW TO USE THIS ENTRANCE MAT SELECTOR?

- 1 | Identify the type of area where you will install the carpet in relation to traffic
(*ex: heavy traffic*)
- 2 | Refer to the corresponding collection of products (*ex: Performance Collection*)
- 3 | For best performance, combine a scraper, a wiper/scraper and a wiper from the same collection (*ex: Commercial Clean Machine[®], Marathon[™] and Dust-Star[™]*)

FOR BEST RESULTS, COMBINE THREE TYPES OF MATS IN THE FOLLOWING ORDER:

1 | **SCRAPER**

- Exterior usage or between two doors
- Aggressive scraper surface, which will capture the majority of dirt from the soles of shoes
- Does not absorb moisture, which facilitates maintenance

2 | **WIPER/SCRAPER**

- Interior usage or between two doors
- Irregular surface which enables trapping the moderate dirt that was not captured at the scraper level.
- Moderately retains water and moisture that may later evaporate or be extracted at the right time.

3 | **WIPER**

- Interior usage
- Plays a major role in the retention of water and fine dust.
- Minimizes the risk of slipping and falling related to wet entrances and corridors.

PERFORMANCE

PRESTIGE

CLASSIC

VALUE

LIGHT TRAFFIC

**Under 125
persons per day!**

- Small business
- Side entrance
- Dental office
- Boutique

LIGHT- MEDIUM TRAFFIC

**Between 125 & 500
persons per day!**

- Office building
- Small retail store
- Bank/Postal service
- Car dealership
- Church
- Motel & Inn

MEDIUM- HEAVY TRAFFIC

**Up to 1,500
persons per day!**

- Convenience store
- Restaurant
- Theater
- Museum
- Convention Center
- Hotel

HEAVY TRAFFIC

**Over 1,500
persons per day!**

- University
- Airport
- Hospital
- Large retail store
- Shopping mall
- School